



WEATHER-CLAD SEMIGLOSS FINISH

EBE – W400

DESCRIPTION	SYSTEM RECOMMENDATION															
<p>Superior quality washable exterior/interior acrylic copolymer emulsion Semigloss finish. This product has been formulated to provide excellent exterior durability, washability and stain resistance.</p>	<p>Concrete Blocks:</p> <table border="0"> <tr> <td>Recommended Primer</td> <td>1 Coat</td> <td>As Recommended</td> </tr> <tr> <td>Heavy Duty Block Filler <u>or</u></td> <td>1 Coat</td> <td>250 Microns DFT</td> </tr> <tr> <td>Acrylic Latex Putty Int.</td> <td>1 Coat</td> <td>250 Microns DFT</td> </tr> <tr> <td>Recommended Primer</td> <td>1 Coat</td> <td>As Recommended</td> </tr> <tr> <td>Weatherclad Semigloss</td> <td>2 Coats</td> <td>25 Microns DFT per coat</td> </tr> </table>	Recommended Primer	1 Coat	As Recommended	Heavy Duty Block Filler <u>or</u>	1 Coat	250 Microns DFT	Acrylic Latex Putty Int.	1 Coat	250 Microns DFT	Recommended Primer	1 Coat	As Recommended	Weatherclad Semigloss	2 Coats	25 Microns DFT per coat
Recommended Primer	1 Coat	As Recommended														
Heavy Duty Block Filler <u>or</u>	1 Coat	250 Microns DFT														
Acrylic Latex Putty Int.	1 Coat	250 Microns DFT														
Recommended Primer	1 Coat	As Recommended														
Weatherclad Semigloss	2 Coats	25 Microns DFT per coat														
RECOMMENDED USES	<p>Primers Recommended:</p> <ul style="list-style-type: none"> Acrylic Primer Sealer (S) <u>or</u> (W) Latex Wall Primer Wall & Wood Primer 															
<p>For use over prepared substrate such as drywall, plaster, vinyl sidings, plywood, concrete block and other masonry and metal surfaces in architectural application.</p>	<p>Iron and Steel:</p> <table border="0"> <tr> <td>Latex Metal Primer</td> <td>1 Coat</td> <td>50 Microns DFT</td> </tr> <tr> <td>Weatherclad Semigloss</td> <td>2 Coats</td> <td>25 Microns DFT per coat</td> </tr> </table>	Latex Metal Primer	1 Coat	50 Microns DFT	Weatherclad Semigloss	2 Coats	25 Microns DFT per coat									
Latex Metal Primer	1 Coat	50 Microns DFT														
Weatherclad Semigloss	2 Coats	25 Microns DFT per coat														
CHARACTERISTICS	<p>Asbestos Siding, Gypsum Board:</p> <table border="0"> <tr> <td>Masonry Conditioner</td> <td>1 Coat</td> <td>25 Microns DFT</td> </tr> <tr> <td>Weatherclad Semigloss</td> <td>2 Coats</td> <td>25 Microns DFT per coat</td> </tr> </table>	Masonry Conditioner	1 Coat	25 Microns DFT	Weatherclad Semigloss	2 Coats	25 Microns DFT per coat									
Masonry Conditioner	1 Coat	25 Microns DFT														
Weatherclad Semigloss	2 Coats	25 Microns DFT per coat														
<p>Color: Wide range of colors available Finish: Semigloss Volume Solid: 35.0% ± 1% Specific Gravity: 1.2 KG / ltr Recommended DFT: 25 Microns Spreading Rate@DFT: 14.00 m² / ltr or 53.00 m² / US gallon Flash Point: 94 °C Drying Schedule: @ 25 °C/R.H.50 Dry to Touch: 1 Hour To Handle: 18 Hours To Recoat: 7 Hours Shelf Life: 18 months, unopened at 25 °C Reducer/Clean Up: Water</p>	<p>Aluminum and Galvanized Steel (Self Prime):</p> <table border="0"> <tr> <td>Weatherclad Semigloss</td> <td>2 Coats</td> <td>25 Microns DFT per coat</td> </tr> </table>	Weatherclad Semigloss	2 Coats	25 Microns DFT per coat												
Weatherclad Semigloss	2 Coats	25 Microns DFT per coat														
APPLICATION PROCEDURES	<p>Wood/Fiber Board:</p> <table border="0"> <tr> <td>Wall & Wood Primer</td> <td>1 Coat</td> <td>50 Microns DFT</td> </tr> <tr> <td>Weatherclad Semigloss</td> <td>2 Coats</td> <td>25 Microns DFT per coat</td> </tr> </table>	Wall & Wood Primer	1 Coat	50 Microns DFT	Weatherclad Semigloss	2 Coats	25 Microns DFT per coat									
Wall & Wood Primer	1 Coat	50 Microns DFT														
Weatherclad Semigloss	2 Coats	25 Microns DFT per coat														
<p>Surface Preparation: Surface must be dry, clean and in sound condition. Remove oil, dust, dirt, millscale or other foreign substance to ensure good adhesion. Minimum surface preparation methods to be followed for (1) Iron and Steel – SSPC-SP3-63 (2) Aluminum and Galvanizing – SSPC-SP1-63. (3) Wood to be sanded and/or scraped to a clean smooth surface. Allow weathering of new galvanized steel for six months prior to coating. Mildew must be removed prior to painting by washing with a solution of 1 quart household bleach and 3 quarts warm water.</p> <p>Application Methods:</p> <table border="0"> <tr> <td>Conventional Spray:</td> <td>Reduce up to 12% with water</td> </tr> <tr> <td>Airless Spray:</td> <td>Reduce up to 12% with water</td> </tr> <tr> <td>Brush/Roller:</td> <td>Reduction not recommended</td> </tr> </table>	Conventional Spray:	Reduce up to 12% with water	Airless Spray:	Reduce up to 12% with water	Brush/Roller:	Reduction not recommended	<p>*For further information on recommended products please refer to Sherwin Williams Saudi Arabia Painting & Coatings System Guide.</p> <p>**For further information on surface preparation methods and application procedures please refer to Sherwin Williams Saudi Arabia Surface Preparation bulletin.</p>									
Conventional Spray:	Reduce up to 12% with water															
Airless Spray:	Reduce up to 12% with water															
Brush/Roller:	Reduction not recommended															
APPLICATION PROCEDURES	SPECIAL TIPS															
<p>Excessive reduction of material can affect the film build, appearance, and adhesion. Any further specific technical information can be obtained from SWSA if you email ask@sherwinwilliams.ae</p>	<p>Excessive reduction of material can affect the film build, appearance, and adhesion. Any further specific technical information can be obtained from SWSA if you email ask@sherwinwilliams.ae</p>															
APPLICATION PROCEDURES	SAFETY PRECAUTIONS															
<p>Spray under well-ventilated conditions. Do not breathe or inhale mist. When spraying, wear air mask. Avoid skin contact. Spillage on skin should immediately be removed with suitable cleanser, soap and water. Eyes should be flushed with water and medical attention sought immediately.</p>	<p>Spray under well-ventilated conditions. Do not breathe or inhale mist. When spraying, wear air mask. Avoid skin contact. Spillage on skin should immediately be removed with suitable cleanser, soap and water. Eyes should be flushed with water and medical attention sought immediately.</p>															